For the information of Railway Staff only.



EASTERN REGION

SUPPLEMENTARY NOTICE of SIGNALLING ALTERATIONS

affecting the working of the line

from

Sunday 5 October 1986.

Diss and Tivetshall —

abolition of signal boxes.

M042-6504

C. McKeever Regional Operations Manager.

SIGNALLING RECORD SOCIETY

www.s-r-s.org.uk

DIGITAL ARCHIVE

This PDF Copy has been provided free of charge by David Allen in order to assist your research into UK signalling.

This file is one of a number scanned by David Allen using material from his own collection and from the collections of Phil Deaves, Robert Dey, David Ingham, Simon Lowe, John McCrickard, John Midcalf, Roger Newman, Richard Pulleyn and Chris Wolstenholmes. Thank you one and all. Many of the original documents are now in the SRS Archive or at the National Railway Museum.

You may also like to provide copies of Signalling Notices and Weekly (and periodical) Operating Notices as scans or as originals. The SRS is always willing to accept donations of any signalling or signalling related material for inclusion in the Society's Archive. Please contact the <u>Archivist</u> in the first instance.

For a list of PDFs currently available visit the list of <u>Weekly</u> Notices or <u>Signalling</u> Notices page.

If you have benefited from this PDF copy, why not join the Signalling Record Society and receive support for your researches and access to the Society's Archives

Members receive "The Signalling Record" six times annually plus a newsletter and have the opportunity to purchase SRS <u>books</u> and other <u>publications</u> at a discount. They also have access to back issues of The Newsletter and The Signalling Record which are only available to members. These contain a wealth of information accumulated since 1970, much of which is not readily available anywhere else.

In addition, Members have the opportunity to join signalling related visits to locations on the UK national and London Underground systems; and to other UK Railways.

To join the Signalling Record Society visit

www.s-r-s.org.uk/membform.html

SUNDAY 5 OCTOBER - DISS-TIVETSHALL-SWAINSTHORPE

Diss and Tivetshall signalboxes will be abolished.

New colourlight signalling will be commissioned and the Track Circuit Block Regulations will apply. Swainsthorpe will become the new outpost to Colchester signalbox.

All points in the vicinity of Diss Station will be controlled from Colchester and the new facing crossover at the south end of the Station Platforms will be brought into use.

The trailing crossover at Swainsthorpe will be secured out of use pending removal.

Reference should be made to the attached diagram(s).

Alterations to Existing Signalling

All former Diss controlled signals which have been retained (south of Diss Station) will be replated and/or renumbered with Colchester (CO) prefixes.

The position 4 Junction Indicator and the position light on Down Main Signal CO429 (former Diss Signal D23) and the position light and route indicator on Up Main signal CO430 (former Diss Signal D3) will be brought into use in conjunction with the new facing crossover referred to above.

Flordon Emergency Crossover Ground Switch Panel at 106m. 64chs.

The new trailing crossover at 106m. 64chs. will be brought into use operated from the new "Flordon Emergency Crossover Ground Switch Panel" released from Colchester Signal Box. Telephone communication will be provided between the Ground Switch Panel and the signal box.

Level Crossings

•

Hales Street Level Crossing at 100m 27chs

Tivetshall Level Crossing at 100m 43chs

These crossings will be converted to automatic half-barrier level crossings. Telephone communication will be provided between the crossings and Colchester Signal Box.

Wrong Direction Working

Hales Street and Tivetshall Level Crossing barriers are equipped to work automatically when approached in the wrong direction and for this purpose, combined St. Andrews Cross/50 m.p.h. speed restriction signs (applicable to each wrong direction rail approach) will be provided. The location of these signs is shown on the diagram(s).

All telephones at existing automatic half-barrier level crossings, previously communicating with Diss or Tivetshall will now communicate with Colchester Signal Box.

Automatic Warning System

A.W.S. will be provided in conjunction with all new colour-light signals. //Continued

3103/3461m,'1


| | | Aspect | | |
|--|----------------------|-----------------------------|----------------------------------|--|
| <u>Signal</u> | Line | Aspect | Route Indication | <u>Application to or</u> Towards |
| | | M=Main PL=Position Light | | |
| C0429 | Down Main | M | | CO431 Signal Down Main |
| 0429 | Down Marn | M | Junction Indicator Position 4 | CO431 Signal Up Main |
| | | PL | | Down Main Platform |
| | | PL | Junction Indicator Position 4 | Line Occupied Up Main Platform Line occupied |
| C0430 | Up Main | Μ | | CO424 Up Main |
| | | PL | X | Down Main "Limit of Shunt" |
| CO433 (Down D | Up Main irection) | M † | | CO439 Signal Down Main |
| (2000) 2 | | PL | U | Up Main 1413 Position Light |
| | | PL | S | Up Siding |
| † - cleared in conjunction with 1413 Position Light. | | | | |
| C0436 | Up Main | M | | CO430 Signal Up Main |
| | | PL PL | Y S | Goods Yard Up Siding |
| Position Light Signals (Controlled from Colchester SB) | | | | |
| 1408 | Up Siding | | | Up Main |
| 1409 | Up Siding | | D | Down Main |
| | | | Н | Headshunt |
| 1411 | Goods Yard | | D H | Down Main Headshunt |
| 1412 | U. Main | | ** | Down Main |
| 1413 | Up Main | | | |
| 1414 | Headshunt | | Y S | Goods Yard Up Siding |
| 1416 | Down Main | | Y | Goods Yard |
| | | | S U | Up Siding Up Main |
| | | | | Down Main "Limit of Shunt" |
| | | | | Dimit of Bridhe |


Description of Signals (Routing Signals Only)


τ.


A double-sided "OFF" indicator will be provided in the cess of the Headshunt which will be illuminated when 1414 position light signal is cleared.

• •









E = Denotes SEMI - AUTOMATIC SIGNAL - The Rule Book, Section C, Clauses 2.4.&3.3.4

3 = ROUTE INDICATOR (Numeral indicates total number of routes).

= POSITION LIGHT SIGNAL - Associated with main aspect = POSITION LIGHT SIGNAL - Not associated with main aspect (Ground shunting signals)

The Rule Book. Section C. Clauses 3.1.3.&5.1

 $\boxtimes \rightarrow$ = LIMIT OF SHUNT INDICATOR - The Rule Book, Section C, Clauses 3.3.2. & 5.6.