

1
UP
MAIN
DISTANT
4
3
2

2
UP
MAIN
HOME
20

3
UP
MAIN
STARTING

4
UP
MAIN
ADVANCED
STARTING
LINE
CLEAR

10
UP
MAIN
DETONATORS
OFF
ON

11
DISC
FOR
14
20
14

12
DISC
FOR
14
21
20
14
OR
45
44
21
20
14

13
DISC
FOR
14
25
21
20
14

14
MAIN
XOVER
(LOWER)

15
UP
MAIN
TO
UP
LOOP
HOME
21
20
OR
45
44
21
20

16
SHUNTING
SPUR
TO
UP
LOOP
STARTING
NIL
OR
45
44

17
UP
LOOP
TO
UP
BRANCH
STARTING

18
UP
LOOP
TO
UP
MAIN
STARTING
45
44

19
UP
MAIN
TO
SIDING
HOME
25
21
20

20
FPL
FOR
21

21
UP
MAIN
FACING
UP
LOOP

23
SHUNTING
SPUR
TO
SIDING
STARTING
25

24
SHUNTING
SPUR
FACING
DOWN
LOOP

25
UP
LOOP
FACING
SIDINGS

26
DISC
FOR
14
14

LACOCK

S322/7/1

27
DISC
FOR
25
21
25
26

28
DISC
FOR
25
25

29
SHUNTING
SPUR
TO
DOWN
LOOP
STARTING
24

30
BACKING
FROM
DOWN
LOOP
TO
DOWN
BRANCH

31
BACKING
FROM
UP
LOOP
TO
DOWN
MAIN
(DISC)
21
26

32
BACKING
FROM
UP
LOOP
TO
SHUNTING
SPUR
(DISC)

33
DISC
AT
38
NIL
OR
21
26

34
DISC
FOR
35
35

35
DOWN
LOOP
FACING
DOWN
MAIN

36
SIDINGS
TO
UP
MAIN
STARTING
45
44
41

37
SIDINGS
TO
UP
BRANCH
STARTING
38

38
UP
BRANCH
SIDINGS

39
DISC
FOR
38
38

40
UP
LOOP
AND
DOWN
BRANCH
FACINGS
TO
CROSS

41
COMPOUND
POINTS
IN
UP
BRANCH
38
40

42
DOWN
BRANCH
TO
SIDINGS
HOME
41

43
DOWN
BRANCH
TO
UP
LOOP
HOME
40

44
UP
MAIN
DOWN
LOOP

45
COMPOUND
POINTS
IN
DOWN
BRANCH
40

46
DISC
FOR
44
41
44
45

LACOCK

S322/7/2

47
DISC
FOR
44
21
26
44
45
OR
44
45

48
DISC
FOR
44
44

49
DOWN
MAIN
FACING
DOWN
LOOP

50
FPL
FOR
49

51
DOWN
LOOP
TO
SHUNTING
SPUR
STARTING
24

52
DOWN
LOOP
TO
DOWN
MAIN
STARTING
35

53
DOWN
BRANCH
TO
DOWN
LOOP
HOME

54
DOWN
MAIN
TO
DOWN
LOOP
HOME
49
50

55
DISC
FOR
56
56

56
MAIN
XOVER
(UPPER)

57
DISC
FOR
56
50
56
OR
49
50
56

58
DOWN
MAIN
DETONATORS
OFF
ON

64
DOWN
MAIN
ADVANCED
STARTING
LINE
CLEAR

65
DOWN
MAIN
STARTING

66
DOWN
MAIN
HOME
50

67
DOWN
MAIN
DISTANTS
64
65
66

IVORINES "REQUIRED BY 14. 3. 42"
82/8151

R 282

LACOCK	
	5322/7/3