

0  
UP  
MAIN  
DISTANT  
1  
2  
6

1  
UP  
MAIN  
HOME

2  
UP  
MAIN  
INNER  
HOME

3  
UP  
BRANCH  
TO  
MAIN  
DISTANT  
10  
6  
5  
4

4  
UP  
BRANCH  
TO  
MAIN  
HOME  
10

5  
UP  
BRANCH  
TO  
MAIN  
INNER  
HOME  
10

6  
UP  
MAIN  
STARTING  
LINE  
CLEAR

7  
UP  
SIDING  
TO  
MAIN  
STARTING  
AND DISC  
FOR No.14  
(SELECTED)  
8  
OR  
14

9  
BRANCH  
SWITCH  
TO  
No.2  
NOTCH  
NIL  
TO  
No.3  
NOTCH  
10 | 6  
11 | 5  
12 | 4  
16 | 3  
17 |

10  
UP  
MAIN  
FROM  
BRANCH

11  
DOWN  
MAIN  
FACING  
TO  
BRANCH  
10

12  
FPL  
FOR  
No.11  
NIL  
OR  
10  
11

13  
MAIN  
SWITCH  
TO  
No.2  
NOTCH  
NIL  
TO  
No.3  
NOTCH  
12 | 6  
18 | 2  
19 | 1  
20 | 0

14  
MAIN  
TOVER

<u>15</u>	<u>16</u>	<u>17</u>	<u>18</u>	<u>19</u>
DISCS	DOWN	DOWN	DOWN	DOWN
FOR	BRANCH	MAIN	MAIN	MAIN
NOS	STARTING	TO	STARTING	HOME
8 & 14	LINE	BRANCH		12
(SELECTED)	CLEAR	HOME		
<u>8</u>		<u>10</u>		
<u>OR</u>		11		
<u>12</u>		<u>12</u>		
<u>14</u>				
<u>OR</u>				
<u>10</u>				
11				
12				
14				

20  
 DOWN  
 MAIN  
 DISTANT  
 12  
 18  
 19

DETONATORS : 2 SMALL 2-LEVER FRAMES

WORLE JCN	
	S