DOWN MAIN HOME — 7

DOWN
MAIN
INTERMEDIATE
HOME

DOWN
MAIN
INNER
HOME
TO
No 3
LINE

26

DOWN
MAIN
INNER
HOME
TO
No 4
LINE
-47

26

UP
MAIN
FACING
FROM
DOWN
MAIN

DOWN
MAIN
INTERMEDIATE
DRAW
AHEAD
TO
CARRIAGE
RECEPTION
LINE
-9

DOWN
MAIN
FACING

CARRIAGE
RECEPTION
LINE

DRAW
AHEAD
UP
CARRIAGE
RECEPTION
LINE
TO

SPUR

DOWN
MAIN
INNER
HOME
TO
No 2
LINE
37
32
28

2 13 ····

CARRIAGE
RECEPTION
—
FILISHING
APRON

DOWN
MAIN
INNER
HOME
TO
No 1
LINE
32

28

POSITION
LIGHT
FLUSHING
APRON
TO
DOWN
CARRIAGE
RECEPTION
OR
UP
SIDING
—
13

DON POSITION LIGHT DOWN MAIN INNER HOME TO SIDINGS

GG 48

26

POSITION
LIGHT
ALONG
DOWN
CARRIAGE
RECEPTION
OR TO
UP
SIDING

POSITION LIGHT UP CARRIAGE RECEPTION TO FLUSHING APRON OR ALONG UP CARRIAGE

RECEPTION

21 DOWN CARRIAGE RECEPTION LINE FACING UP SIDING

22 POSITION LIGHT UP SIDING TO FLUSHING APRON OR UP CARRIAGE RECEPTION

21

23 POSITION LIGHT **FOR** 29B 29 28

24 POSITION LIGHT FOR 25 25 28

CARRIAGE RECEPTION LINE SAFETY

POSITION LIGHT DOWN MAIN TO SIDINGS OR No 4 LINE OR No 3 LINE

28 POSITION LIGHT ΑT 34B 34 26 OR NIL

UP CARRIAGE LINE UP SIDING

32 DOWN MAIN FACING No 1 LINE

34 UP MAIN FACING No 1 LINE

37 No 1 LINE FACING No 2 LINE

39 POSITION LIGHT ΑT 29A 29 OR 25

43 POSITION LIGHT DOWN SIDING TO SEA SIDINGS

POSITION
LIGHT
AT
46A
—
NIL
OR
46
26

UP
MAIN
FACING
SEA
SIDINGS

DOWN
MAIN
TO
No 3
LINE
FACING
No 4
LINE

No 4
LINE
FACING
—
SIDINGS
—
47

DRAW
AHEAD
DOWN
SIDINGS
TO 39
SIGNAL
OR ALONG
DOWN
SIDINGS
—
34

48 OR NIL 52
POSITION
LIGHT
ALONG
DOWN
SIDINGS

DRAW
AHEAD
No 4 LINE
TO 39
SIGNAL
OR
SEA
SIDINGS
34

47
OR
46
47

DRAW
AHEAD
No 3 LINE
TO 39
SIGNAL
OR
SEA
SIDINGS
34

OR 46 DRAW
AHEAD
No 1
LINE
TO
39
SIGNAL

DRAW
AHEAD
No 2
LINE
TO
39
SIGNAL
—

UP
MAIN
OUTER
ADVANCED
STARTING

UP
CARRIAGE
RECEPTION
LINE
STARTING
TO UP
MAIN
9

UP MAIN ADVANCED STARTING No 1
LINE
STARTING
TO UP
MAIN
—
32