

0.
DOWN
MAIN
DISTANT
18.
1.
2.

1.
DOWN
MAIN
HOME
18.

2.
DOWN
MAIN
START'G
LINE
CLEAR

3.
DOWN
MAIN
TO
UP
BRANCH
HOME

33.
19.
18.
17.

4.
UP
BRANCH
START'G
33.

5.
UP
BRANCH
ADV'CD
START'G
41.

6.
UP
BRANCH
SHUNT
41.

8.
UP
BRANCH
TO
DOWN
SIDINGS
START'G

31.
32.
33.

12.
DOWN
MAIN
DETONATORS
OFF
ON

13.
UP
BRANCH
DETONATORS
OFF
ON

14.
DISC
FOR
No 16B
33.
19.
18.
17.
16.
OR
18.
16.

15.
F.P.L.
FOR
No 16
16.

16.
MAIN
X-OVER

17.
UP
BRANCH
SAFETY
19.

18.
F.P.Ls
FOR
No 19
&
No 20B
NIL
OR
19.

19.
DOWN
MAIN
FACING
TO
UP
BRANCH

20.
UP
BRANCH
FACING
DOWN
BRANCH
19.

21.
F.P.L.
FOR
No 20A
NIL
OR
20.

22.
DISC
FOR
No 16A
16.
15.

23.
DISC
FOR
No 17
19.
17.
16.
15.
22.

26.
TO
UP
BRANCH
START'G
29.

27.
TO
DOWN
SIDINGS
START'G
29.
31.
32.
34.

29.
UP
BRANCH
SIDINGS

AMENDMENTS

ROTHERWAS JC

LEVER LEADS

SHEET 1 OF 2 SHEETS

BRITISH RAILWAYS
WESTERN REGION
SIGNAL ENGINEER'S OFFICE
READING

DRAWN	A.J.M.	DATE	12-3-57
CHECKED	28.6	DATE	18-3-57
APPROVED		DATE	

S 2248/7/1

30.
DISC
FOR
No 31
31.

31.
DOWN
BRANCH
SIDINGS

32.
UP
BRANCH
FACING
DOWN
SIDINGS
31.

33.
F.P.L.
FOR
No 32
NIL
OR
31.
32.

34.
COMP'D
29
31.
32.

38.
DISC
FOR
No 29
29

39.
DOWN
TO
UP
SIDINGS
STARTS
29.
31.
32.
34.

40.
DOWN
SIDINGS
TO
BRANCH
STARTING

21.
31.
OR
16.
15.
19.
20.
21.
31.

41.
DOWN
BRANCH
FACING
UP
BRANCH

42.
F.P.L.
FOR
No 41

43.
DOWN
BRANCH
DETONATORS
OFF
ON

44.
UP
MAIN
DETONATORS
OFF
ON

45.
F.P.L.
FOR
No 22
19
22.


50.
UP
MAIN
START'G
LINE
CLEAR

51.
DOWN
BRANCH
TO
UP
MAIN
STARTING
16.
15.
19.
20.
21.
22.

52.
DOWN
BRANCH
HOME
21.
42.
OR
19.
20.
21.
42.

53.
UP
MAIN
HOME

54.
UP
MAIN
DISTANT
53
50.



AMENDMENTS

ROTHERWAS JC

LEVER LEADS

SHEET 2 OF 2 SHEETS

BRITISH RAILWAYS
WESTERN REGION
SIGNAL ENGINEER'S OFFICE
READING

DRAWN A.T.M. DATE 12-3-57
CHECKED *SL* DATE 18-3-57
APPROVED DATE

5 2248/7

0
DOWN
MAIN
DISTANT
18
1
2

1
DOWN
MAIN
HOME
18

14
DISC
FOR
16B
33
19
18
17
16
OR
18
16

15
F.P.L.
FOR
16A
16

17
UP
BRANCH
SAFETY
19

18
F.P.L.S
FOR
19 & 20B
NIL
OR
19

20
UP
BRANCH
FACING
DOWN
BRANCH
19

21
F.P.L.
FOR
20A
NIL
OR
20

22
DISC
FOR
16A
16
15

23
DISC
FOR
17
19
17
16
15
22

40
DOWN
SIDINGS
TO
BRANCH
STARTING
21
31
OR
16
15
19
20
21
31

51
DOWN
BRANCH
TO
UP
MAIN
STARTING
16
15
19
20
21
22

52
DOWN
BRANCH
HOME
21
42
OR
19
20
21
42

54
UP
MAIN
DISTANT
53
50

40/5137
IVORINES & CASTINGS

4. 3. 1957
ME GOWER, ABERGAVENNY

ROTHERWAS JCN

S

0
DOWN
MAIN
DISTANT
18
1
2

1
DOWN
MAIN
HOME
18

14
DISC
FOR
16B
33
19
18
17
16
OR
18
16

15
F.P.L.
FOR
16A
16

17
UP
BRANCH
SAFETY
19

18
F.P.L.S
FOR
19 & 20B
NIL
OR
19

20
UP
BRANCH
FACING
DOWN
BRANCH
19

21
F.P.L.
FOR
20A
NIL
OR
20

22
DISC
FOR
16A
16
15

23
DISC
FOR
17
19
17
16
15
22

40
DOWN
SIDINGS
TO
BRANCH
STARTING
21
31
OR
16
15
19
20
21
31

51
DOWN
BRANCH
TO
UP
MAIN
STARTING
16
15
19
20
21
22

52
DOWN
BRANCH
HOME
21
42
OR
19
20
21
42

54
UP
MAIN
DISTANT
53
50

40/5137
IVORINES & CASTINGS

4. 3. 1957
Mr GOWER, ABERGAVENNY