



British Rail

Southern

SOUTH WESTERN DIVISION

**ALTERATIONS TO SIGNALLING
AND PERMANENT WAY
BETWEEN
ROMSEY AND DUNBRIDGE
ON
SUNDAY, 17th OCTOBER, 1982**

DRIVERS TO KEEP A GOOD LOOK-OUT FOR HAND SIGNALS

Romsey signal box will be abolished and the area of control will be transferred to Eastleigh signal box. Track Circuit Block working will be introduced on both lines between Romsey and Dunbridge. The signal post telephones at present giving communication with Romsey signal box, together with that at signal E.890, will give communication with Eastleigh signal box.

Full details of the signalling alterations are shown on the enclosed diagram.

Wimbledon
September 1982

(R/SA1406/33/16)

F. B. Whitehall
Divisional Manager

SIGNALLING RECORD SOCIETY

www.s-r-s.org.uk

DIGITAL ARCHIVE

This PDF Copy has been provided free of charge by David Allen in order to assist your research into UK signalling.

This file is one of a number scanned by David Allen using material from his own collection and from the collections of Phil Deaves, Robert Dey, David Ingham, Simon Lowe, John McCrickard, John Midcalf, Roger Newman, Richard Pulleyn and Chris Wolstenholmes. Thank you one and all. Many of the original documents are now in the SRS Archive or at the National Railway Museum.

You may also like to provide copies of Signalling Notices and Weekly (and periodical) Operating Notices as scans or as originals. The SRS is always willing to accept donations of any signalling or signalling related material for inclusion in the Society's Archive. Please contact the [Archivist](#) in the first instance.

For a list of PDFs currently available visit the list of [Weekly](#) Notices or [Signalling](#) Notices page.

If you have benefited from this PDF copy, why not [join](#) the Signalling Record Society and receive support for your researches and access to the Society's Archives

Members receive "The Signalling Record" six times annually plus a newsletter and have the opportunity to purchase SRS [books](#) and other [publications](#) at a discount. They also have access to back issues of The Newsletter and The Signalling Record which are only available to members. These contain a wealth of information accumulated since 1970, much of which is not readily available anywhere else.

In addition, Members have the opportunity to join signalling related visits to locations on the UK national and London Underground systems; and to other UK Railways.

To join the Signalling Record Society visit

www.s-r-s.org.uk/membform.html

ALL DISTANCES IN YARDS.



= JUNCTION INDICATORS – The Rule Book, Section C, Clause 3.1.6.



= GREEN ASPECT



= YELLOW ASPECT



= RED ASPECT

} The Rule Book, Section C, Clause 3.1.1.



= ROUTE INDICATOR (Numeral indicates total number of routes).



= POSITION LIGHT SIGNAL – The Rule Book, Section C, Clauses 3.1.3. and 5.3. or 3.1.4. and 5.1.1.



= BANNER REPEATING SIGNAL – The Rule Book, Section C, Clauses 3.3.1 and 5.5.



= Denotes AUTOMATIC SIGNAL – The Rule Book, Section C, Clauses 2.3 and 3.3.4.



= Denotes SEMI-AUTOMATIC SIGNAL – The Rule Book, Section C, Clauses 2.4 and 3.3.4.



= A.W.S. TRACK EQUIPMENT



= TELEPHONE.



= POSITION LIGHT SHUNTING SIGNAL – The Rule Book, Section C, Clauses 3.1.5 and 5.2.



= As above but with YELLOW light instead of red light.




= LIMIT OF SHUNT INDICATOR – The Rule Book, Section C, Clauses 3.3.2 and 5.6.




= SIGNAL BOX.



= GROUND FRAME (Numeral indicates total number of levers).



= RETURN BELL COMMUNICATION PLUNGER.



= TRAIN READY TO START PLUNGER.



= PLATFORM STARTING SIGNAL "OFF" INDICATOR.



= "DIAMOND" SIGN – The Rule Book, Section K, Diagram No. 1.



= NOTICE BOARD OR SIGNAL WHICH IS FLOODLIT DURING DARKNESS.



= SPRING TRAILING POINTS.




= PERMANENT SPEED RESTRICTION ADVANCE WARNING INDICATOR

Where the suffix letter 'R' is shown with the number of a colour light signal, this denotes that the signal acts as distant for the signal ahead bearing the same number.


SIGNAL APPLICATIONS

Signal No.	Aspect	Indication	Application
E884	Running	Nil	Along Up Salisbury
		Pos 4	Up Salisbury to Up Test Valley
E886	Running	'E'	Down Salisbury to Up Salisbury
		'R'	Down Salisbury to Up Test Valley
E995	Shunting	Nil	Up Salisbury to Down Salisbury
		Nil	Along Up Salisbury to Limit of Shunt



EXISTING SIGNALLING MODIFIED AS SHOWN

ALL CONTROLS TRANSFERRED FROM ROMSEY
(PREFIX 'WBW') TO EASTLEIGH (PREFIX 'E')



SIGNAL INSTRUCTION
No. 69 SWD

