

59
 DOWN
 MAIN
 STARTING
 TO
 BRANCH
18
 19

60
 DOWN
 UP
 MAIN
 STARTING
 TO
 DOWN
 BRANCH
18
 19
 26

61
 DOWN
 UP
 MAIN
 STARTING
 TO
 DOWN
 MAIN
19
 26

62
 DOWN
 MAIN
 (INNER) *
 HOME
 TO
 UP
 MAIN
19
 52
 53

63
 DOWN
 MAIN
 STARTING
19

64
 DOWN
 MAIN
 HOME
19
 45
 53

* WORDING OBLITERATED

YEOVIL PEN MILL	9. 1985
LEVER LEADS	