

0
DOWN
MAIN
HOME
9
OR
11
10
9

1
DOWN
MAIN
INNER
HOME
9

2
DOWN
MAIN
START'G
30

3
DOWN
MAIN
TO
BACK
PLATF'M
LINE
INNER
HOME
11
10
9

4
BACK
PLATF'M
LINE
TO
DOWN
MAIN
START'G
34

5
DOWN
MAIN
ADV'CD
START'G

6
DOWN
MAIN
TO
BACK
PLATF'M
CALLING
ON
11
10
9

8
DISC
FOR
No. 12
12

9
F.P.L.
FOR
Nos 11 & 14
NIL
OR
11
10

10
F.P.L.
FOR
No. 12

11
DOWN
MAIN
FACING
TO
BACK
PLATF'M
LINE

12
BACK
PLATF'M
LINE
FACING
TO
SIDINGS
11

13
DISC
FOR
No. 12
11
12

14
DOWN
MAIN
FACING
TO
UP
MAIN

15
DISC
FOR
No. 16
16

16
DOWN
MAIN
UP
SIDINGS

17
DISC
FOR
No. 16
16

18
DISC
FOR
No. 19
19
OR
21
19

19
UP
MAIN
GOODS
SHED

20
DISC
FOR
No. 19
19

DEVIZES	
---------	--

21
GOODS
SHED
UP
SIDING
19

22
DISC
FOR
No. 21
21

24
No. 1
UP
SIDING
SAFETY

25
DISC
FOR
No. 24
24

28
DISC
AT
29
29
OR
24

29
SPRING
POINTS
IN UP
MAIN
(SLOTTED)

30
UP
MAIN
FACING
DOWN
MAIN

31
F.P.L.
FOR
No. 30

32
DISC
FOR
No. 33
34
33

33
BACK
PLATF'M
LINE
FACING
SIDINGS
34

34
UP
MAIN
FACING
TO
BACK
PLATF'M
LINE

35
F.P.L.
FOR
No. 33

36
F.P.L.
FOR
No. 34
31
OR
34
35

37
DISC
FOR
No. 33
34
33

39
UP
MAIN
TO
BACK
PLATF'M
LINE
CALLING
ON
34
35
36

40
UP
MAIN
SHUNT

41
UP
MAIN
ADV'D
START'G

42
BACK
PLATF'M
LINE
TO UP
MAIN
START'G
11

43
UP
MAIN
TO
BACK
PLATF'M
LINE
HOME
34
35
36

44
UP
MAIN
START'G
14

45
UP
MAIN
HOME
31
36

ALL BRASSES EXCEPT No. 28
C. 1951

0
DOWN
MAIN
HOME
9
OR
11
9

3
DOWN
MAIN
TO
BACK
PLATFORM
LINE
INNER
HOME
11
9

6
DOWN
MAIN
TO
BACK
PLATFORM
LINE
CALLING
ON
11
9

8
DISC
AT 14
11
12
9

9
FPLs
FOR
11.12.14
NIL
OR
11
OR
11
12

MR TABER, FROME
2.11.1954

37
DISC
FOR
33
34
33
35

39
UP
MAIN
TO
BACK
PLATFORM
LINE
CALLING
ON
34
35

43
UP
MAIN
TO
BACK
PLATFORM
LINE
HOME
34
35

45
UP
MAIN
HOME
35

35
F.P.L.s
FOR
30.33.34
NIL
OR
34
OR
34
33

MR TABER FROME
8.12. 1953

DEVIZES