

1
DOWN
MAIN
DISTANT
21
5
4
2

2
DOWN
MAIN
HOME
21

3
BRANCH
TO
DOWN
MAIN
HOME
27
23
22
21
20

4
DOWN
MAIN
START'G

5
DOWN
MAIN
ADV'CD
START'G

6
DOWN
MAIN
TO
SIDING
HOME
24
21
OR
46
24
21

7
BRANCH
TO
DOWN
SIDING
HOME
27
24
23
22
21
20
OR
46
27
24
23
22
21
20

17
DOWN
MAIN
DETONATORS
OFF
ON

18
DISC
FOR
No.19
24
19
21
OR
19
21

19
MAIN
✕ OVER

20
FPLs
FOR
Nos 22
AND
30
NIL
OR
27
23
22

FROME SOUTH

S400/7/1

21
FPLS
FOR
Nos 19
23 AND
24
NIL
OR
24
OR
27
23
OR
27
24
23
OR
19
OR
19
24

22
BRANCH
FACING
BRANCH
27
23
OR
27
30

23
DOWN
MAIN
FROM
OR
TO
BRANCH
27

24
DOWN
MAIN
FACING
SIDING

25
DISC
FOR
No.24
START'G
TO
BRANCH
27
24
23
22
21

26
DISC
FOR
No.24
START'G
TO
UP
MAIN
24
19
21

27
UP
MAIN
FACING
BRANCH
SIDING

28
BRANCH
SIDING
SAFETY
27

29
DISC
FOR
No. 28
53
27
28
OR
27
28
OR
33
27
28
32
OR
43
27
28
OR
40
27
28
OR
35
33
27
28
32
OR
35
37
33
27
28
32

30
BRANCH
FACING
27

31
F.P.L.S
FOR
Nos. 27
AND
30
NIL
OR
27
OR
27
30

32
DISC
FOR
No. 33
33
OR
33
35
OR
33
35
37

33
BAY
FACING
MAIN

34
F.P.L.
FOR
No. 33
27
31
33
OR
27
30
31
33
OR
31
33

35
BAY
MILK
SIDING

36
DISC
FOR
No. 35
27
28
31
33
34
35
62
OR
27
30
22
31
33
34
35
64
OR
31
33
34
35
68

37
BAY
SIDING
35

FROME SOUTH

S400/7/3

38
DISC
FOR
No. 37
27
28
31
33
34
35
37
62
OR
27
30
22
31
33
34
35
37
64
OR
31
33
34
35
37
68

39
DISC
FOR
No. 40
40

41
DISC
FOR
No. 40
27
31
40
OR
27
30
31
40
OR
31
40

42
DISC
FOR
No. 43
43

43
UP
MAIN
SIDING

44
DISC
FOR
No. 43
27
31
43
OR
27
30
31
43
OR
31
43

45
DISC
FOR
No. 46
46

46
DOWN
MAIN
SIDING

47
DISC
FOR
No. 46
46
OR
24
46

FROM SOUTH

S400/7/4

48
DISC
FOR
No. 49
53
51
49

49
COMP'D
POINTS
IN
UP
SIDING
53
51

50
DISC
FOR
No. 51
53
51

51
UP
SIDING
DOWN
MAIN
53

52
DISC
FOR
No. 53
53

53
MAIN
TO
CROSS

54
DISC
FOR
No. 53
53
51
49
OR
53
51
OR
27
31
53
OR
27
30
31
53

55
UP
MAIN
DETONATORS
OFF
ON

62
BAY
TO
BRANCH
SIDING
START'G
27
28
31
33
34

63
UP
MAIN
TO
BRANCH
SIDING
START'G
27
28
31

64
BAY
TO
BRANCH
START'G
27
30
22
31
33
34

65
DOWN
MAIN
TO
BRANCH
START'G
23
22
21

66
UP
MAIN
TO
BRANCH
START'G
27
30
22
31

67
UP
MAIN
ADV'CD
START'G

68
BAY
TO
MAIN
START'G
31
33
34

69
DOWN
TO UP
MAIN
START 6
19
21

70
UP
MAIN
START 6
31

71

72
UP
MAIN
HOME
27
30
22
31
OR
31

73
UP
MAIN
DISTANT
[ELECTRIC
SWITCH]
31
67
70
72

FROME SOUTH

S400/7/6