

1
DOWN
MAIN
DISTANT
4
3
2

2
DOWN
MAIN
HOME

3
DOWN
MAIN
START'G

4
DOWN
MAIN
ADV'D
START'G

5
DOWN
MAIN
SHUNT

6
DOWN
MAIN
DETONATORS
OFF
ON

7
DISC
FOR
No. 8
8

8
UP
MAIN
SIDING

9
DISC
FOR
No. 8
8

10
DISC
FOR
No. 11
13
11

11
SIDING
FROM
DOWN
MAIN
13

12
DISC
FOR
No. 13
13

13
MAIN
TO
CROSS

14
DISC
FOR
No. 13
13
11
OR
13

15
UP
MAIN
SIDING

16
DISC
FOR
No. 15
15

17
DISC
FOR
No. 15
15

20
UP
MAIN
START'G

21
UP
MAIN
INNER
HOME

22
UP
MAIN
HOME

23
UP
MAIN
DISTANT
20
21
22

UNDATED BUT PRE 1927

R 282

BURLESCOMBE

S 741/7