

1
GATES
LOCKED
ACROSS
ROAD
UNLOCKED

2
GATES
UNLOCKED
LOCKED
ACROSS
LINE
1
WHEEL

3
UP
WICKET
UNLOCKED
LOCKED

4
DOWN
DISTANT
18
13
9
8
6
5

5
DOWN
HOME
13

6
DOWN
STARTING

7
SIDINGS
TO
DOWN
MAIN
STARTING
18
17

8
DOWN
STOP
18

9
DOWN
ADV'D
STARTING

10
DOWN
SHUNT

13
POINTS
No. 14
UNLOCKED
LOCKED

14
DOWN
MAIN
FACING
UP
MAIN

15
MAIN
TO
CROSS
14

16
SIDING
UP
MAIN
14
15

17
DOWN
MAIN
SIDING
18

18
UP
MAIN
FACING
UNBOLTED
BOLTED
FOR
DOWN
MAIN

19
UP
MAIN
FACING
UNBOLTED
BOLTED
FOR
UP
MAIN

20
DOWN
WICKET
UNLOCKED
LOCKED

22
UP
ADV'D
STARTING

23
UP
STARTING
14

24
DISC
FOR
No. 15
POINTS
14
15

25
SIDING
TO UP
MAIN
STARTING
DISC
14
15
16

26
UP
HOME
19

27
UP
DISTANT
14
19
22
23
26

GARA BRIDGE

S 965/7/2

GARA BRIDGE — BRASS PLATE c1895

1	2	3	4	5	6	7	8	9
GATES LOCKED ACROSS ROAD —— UNLOCKED	GATES UNLOCKED —— LOCKED ACROSS LINE —— 1 WHEEL	UP WICKET UNLOCKED —— LOCKED ——	DOWN DISTANT —— 18 13 9 8 6 5	DOWN HOME —— 13	DOWN STARTING ——	SIDING TO DOWN MAIN STARTING —— 18 17	DOWN STOP —— 18	DOWN ADVANCED STARTING ——
10	13	14	15	16	17	18	19	20
DOWN SHUNT ——	POINTS No. 14 LOCKED —— UNLOCKED	DOWN MAIN FACING —— UP MAIN ——	MAIN —— TO CROSS —— 14	SIDING —— UP MAIN —— 14 15	DOWN MAIN —— SIDING —— 18	UP MAIN FACING UNBOLTED —— BOLTED	FOR DOWN MAIN UNBOLTED —— BOLTED	DOWN WICKET UNLOCKED —— LOCKED ——
22	23	24	25	26	27			
UP ADVANCED STARTING ——	UP STARTING ——	DISC FOR No. 15 POINTS —— 14 15	SIDING TO UP MAIN STARTING DISC —— 14 15 16	UP HOME —— 19	UP DISTANT —— 14 19 22 23 26			

GARA BRIDGE — BRASS PLATES 1934

1	2	3	4	5	6	7	8	9
GATES LOCKED ACROSS ROAD —— UNLOCKED	GATES UNLOCKED —— LOCKED ACROSS LINE —— 1 WHEEL	UP WICKET	DOWN MAIN HOME —— 15 13 OR 16 15 13	DOWN MAIN TO SIDINGS STARTING —— 16 15	DOWN MAIN STARTING —— 18	DISC FOR NO.17 —— 18 17	DOWN INTER- MEDIATE STARTING —— 18	DOWN ADVANCED STARTING ——
10	13	14	15	16	17	18	19	20
DOWN SHUNT ——	F.P.L. FOR NO.14 ——	DOWN MAIN FACING —— FROM UP MAIN ——	F.P.L. FOR NO.16 —— NIL OR 16	DOWN MAIN FACING —— SIDING ——	DOWN MAIN —— SIDING —— 18	UP MAIN FACING —— FROM DOWN MAIN	F.P.L. FOR 18 —— NIL OR 18	DOWN WICKET UNLOCKED —— LOCKED ——
20	21	22	23	24	25	26		
DOWN WICKET	UP MAIN TO SIDING HOME —— 17 18 19	UP ADVANCED STARTING	UP STARTING —— 14	STARTING FROM DOWN TO UP MAIN DISC	DISC FOR NO.16 —— 16	UP MAIN HOME —— 19		