	*		
DOWN DISTANT	2 DOWN HOME (SLOT)	3 Down Starting	DOWN ADV'C'D STARTING
5 DP MAIN SIDING	6 DISC FOR No. 7	MAIN + OVER	8 DP MAIN FACING DOWN MAIN
POINTS NO. 8 DINLOCKED LOCKED	10 UP STARTING	HOW E	12 UP DISTANT
1 8 4 3 2	<u>3</u> 8	<u>6</u> 7	<u>SI</u> <u>II</u> 01

LABEL BOARS MARSH MILLS c. 1895
S 969/7

## MARSH MILLS - BRASS PLATE c1895

11

1	2	3	4	5	6	7	8	9
DOWN DISTANT 8 4 3 2	DOWN HOME (SLOT)	DOWN STARTING — 8	DOWN ADVANCED STARTING	UP MAIN — SIDING	DISC FOR No.7  7	MAIN — +OVER	UP MAIN FACING  DOWN MAIN	POINTS No.8 UNLOCKED — LOCKED
10	11	12						
UP STARTING	UP HOME — 9	UP DISTANT  9 10						

1949

MARSH MILLS - LEVER LEADS c193	MARSH	MILLS -	LEVER	LEADS	c193
--------------------------------	-------	---------	-------	-------	------

1	2	3	4	8	9	10	11	12
DOWN MAIN HOME	DOWN MAIN STARTING ————————————————————————————————————	DOWN MAIN ADVANCED STARTING 21	DOWN MAIN OUTER ADVANCED STARTING	DISC FOR 9 — 9	UP MAIN — UP SIDINGS	DISC FOR 9 — 9	DISC FOR 12 — 12	MAIN +OVER
13	14	15	16	17	18	19	20	21
SPRING POINT IN DOWN MAIN (SLOTTED)	DOWN MAIN UP MAIN FACING	F.P.L. FOR 14	DISC FOR 12 — 12	DISC FOR 19  19 18 OR 19 3	DOWN MAIN TO DEPOT ADVANCED STARTING 20 21	UP MAIN FACING UP SIDINGS	DOWN MAIN FACING — DEPOT	F.P.Ls FOR 19 & 20
22	23	24	25	26	30	31	32	
DISC FOR 13 13 OR 13 16	DEPOT TO DOWN MAIN STARTING 15 20 21 22	DEPOT TO SPUR STARTING	DEPOT TO SIDINGS STARTING — 19 20 21	DEPOT TO UP MAIN STARTING 14 15 20 21	UP MAIN TO UP SIDINGS STARTING 19 21	UP MAIN STARTING — LINE CLEAR	UP MAIN HOME — 14 15 21	

## MARSH MILLS LOCKING ALTERATIONS 7TH MARCH 1944

No. Released By	Locks Normal Locks Either Pos	Releases
Locks to come of	f	May 26th 19 <b>4</b> 3.
3	31	•
18	31	
31	3.18	