

BICKLEIGH — BRASS PLATE c1895

1	2	3	4	5	6	7	8
DOWN DISTANT —	DOWN HOME —	DOWN STARTING —	DOWN SHUNT —	POINTS No. 6 UNLOCKED — LOCKED	DOWN MAIN FACING — UP MAIN	DOWN MAIN — DOWN SIDING — 10	UP MAIN FROM SIDING — DOWN MAIN
10 5 3 2	5	10	10				
9	10	11	12	13	14		
UP SIDING SAFETY OPEN — CLOSED	UP MAIN FACING UNLOCKED — LOCKED FOR DOWN MAIN	UP MAIN FACING UNLOCKED — LOCKED FOR UP MAIN	UP STARTING — 6	UP HOME — 8 11	UP DISTANT — 6 8 11 12 13		

BICKLEIGH — LEVER LEADS 1935 (BRASS LEADS)

1	2	3	4	5	6	7	8	9
DOWN HOME — 13 4 OR 14 13 4	DOWN STARTING — 14 13	DOWN SHUNT — 14 13	F.P.L. FOR No.5	MAINS FACING — UP MAIN	F.P.L. FOR No.5 — NIL OR 5	DISC FOR No.8 — 13 8 — 14 13 8	DOWN MAIN — SIDING	DISC FOR No.8 —
13	14	15	16	17	18	19	20	21
F.P.L. FOR No.14 — NIL OR 14	DOWN MAIN FACING SPUR — DOWN MAIN	DISC FOR No.16 — 16 8 9	SPRING POINT IN DOWN MAIN SLOTTED	BACKING FROM UP MAIN TO SIDING (DISC) — 18	UP SIDING SAFETY — 6 18 OR 5 6 18	DISC FOR No.18 — 6 18 OR 5 6 18	UP TO DOWN MAIN FACING — UP MAIN	F.P.L. FOR No.20 — 20
22	23							
UP MAIN STARTING — 5 6	UP MAIN HOME — 6 20 21 OR 5 6 20 21							