

1
DOWN
MAIN
HOME
22
8

2
DOWN
MAIN
INNER
HOME
24
22

3
DOWN
MAIN
INNER
HOME
TO
DOWN
BRANCH
44
22

5
DOWN
BRANCH
STARTING
44
23

7
DOWN
MAIN
HOME
TO UP
AND
DOWN
BRANCH
39 | 44
38 | 38
9 | 9
8 | 8
OR

8
FPL
FOR
9

9
DOWN
MAIN
FACING
UP
AND
DOWN
BRANCH

10
UP
AND
DOWN
BRANCH
INNER
HOME
TO
DOWN
BRANCH
44
38

11
DOWN
BRANCH
ADVANCED
STARTING

13
DOWN
MAIN
STARTING

14
BACKING
UP
AND
DOWN
BRANCH
TO
DOWN
MAIN
34
9

15
BACKING
UP
MAIN
TO UP
AND
DOWN
BRANCH
39
38
33
OR
44
38
33

16
DOWN
MAIN
DETONATORS
OFF
ON

17
DOWN
BRANCH
DETONATORS
OFF
ON

LANDORE

DRAWN: 12.1961

18
DOWN
MAIN
INNER
HOME
TO
EMERGENCY
ROAD
AND
SHEDS
63
24
22

23
UP
AND
DOWN
BRANCH
DOWN
BRANCH

28
UP
MAIN
UP
BRANCH

33
UP
AND
DOWN
BRANCH
FACING
UP
MAIN

24
DOWN
MAIN
TO
DOWN
BRANCH
FACING
DOWN
MAIN

29
UP
BRANCH
DIESEL
DEPOT
28

34
FPL
FOR
33A

20
BACKING
UP
MAIN

30
DISC
FOR
29B
29

35
UP
AND
DOWN
BRANCH
INNER
HOME
TO
DOWN
GOODS
39
38

26
BACKING
UP
MAIN
TO
UP
BRANCH
27

36
(DISC)
ENGINE
LINE
AND
DOWN
SIDINGS
STARTING
TO
DOWN
GOODS

22
FPL
FOR
24
NIL
OR
62
24

27
DISC
AT
29A
28
OR
28
29

<u>38</u>	<u>39</u>	<u>40</u>
FPL	UP	DISC
FOR	AND	AT
<u>39A</u>	DOWN	<u>39B</u>
	BRANCH	<u>NIL</u>
	<u>FACING</u>	<u>OR</u>
	DOWN	<u>34</u>
	GOODS	<u>39</u>

<u>43</u>	<u>44</u>	<u>45</u>	<u>46</u>	<u>47</u>
FPL	FPL	UP	FPL	DISC
FOR	FOR	AND	FOR	AT
<u>23</u>	<u>45A</u>	DOWN	<u>45B</u>	<u>23</u>
		BRANCH		<u>23</u>
		<u>FACINGS</u>		<u>43</u>
		X OVER		<u>OR</u>
				<u>34</u>
				<u>43</u>

<u>48</u>		<u>52</u>
DISC		DISC
BACKING		AT
UP		<u>54A</u>
DOWN		
BRANCH		
<u>47</u>		

<u>53</u>	<u>54</u>	<u>55</u>	<u>56</u>	<u>57</u>
DISC	UP	DISC	BRANCH	UP
FOR	BRANCH	BACKING	<u>X OVER</u>	BRANCH
<u>54A</u>	<u>FACING</u>	UP	(WEST)	HOME
<u>56</u>	DIESEL	BRANCH		TO
<u>54</u>	DEPOT	TO		DIESEL
		DOWN		DEPOT
		BRANCH		<u>54</u>
		<u>56</u>		

58
DISC
AT
56B
NIL
OR
54
56
OR
46
56

59
BACKING
UP
MAIN
TO
EMERGENCY
ROAD
AND
SHEDS
64
63
61

60
BACKING
UP
MAIN
TO
DOWN
MAIN
61

61
MAIN
XOVER

62
FPL
FOR
63A

63
DOWN
MAIN
FACING
EMERGENCY
ROAD
AND
SHEDS

64
COMPOUND
POINTS
IN
DOWN
MAIN

65
DISC
FOR
63B
61
63
64
OR
24
63

66
DISC
AT
61B
61
OR
24
61

68
BACKING
UP
MAIN
TO UP
SIDINGS
69

69
UP
MAIN
UP
SIDINGS

70
DISC
FOR
69A
&
69B
69

72
UP
BRANCH
DETONATORS
OFF
ON

73
UP
MAIN
DETONATORS
OFF
ON

77
UP
MAIN
ADVANCED
STARTING

78
UP
AND
DOWN
BRANCH
STARTING
TO UP
MAIN
33
34

79
UP
BRANCH
INNER
HOME
TO UP
AND
DOWN
BRANCH
45
46
47

80
UP
MAIN
CALLING
ON

81
UP
MAIN
STARTING

82
UP
BRANCH
INNER
HOME
TO
UP
MAIN
28
46

83
UP
BRANCH
HOME
46

84
UP
BRANCH
INNER
DISTANT
83
82
81
77

85
UP
MAIN
HOME

ALL NEW

	S 1815/7/5
--	------------