

1 *
UP
MAIN
DISTANT
2
3
4

2
UP
MAIN
HOME
17

3 *
UP
MAIN
STARTING

4 *
UP
MAIN
ADVANCED
STARTING

6
UP
MAIN
TO UP
LOOP
HOME
16. 17
OR
30 16 17

7
UP
LOOP
TO UP
MAIN
STARTING
30

12
UP
MAIN
DETONATORS
OFF
ON

16
UP
MAIN
FACING
UP
LOOP

17
FPL
FOR
No. 16
NIL
OR
16

19 *
DISC
FOR
16A
16

20 *
DISC
AT 30B

22
DISC
FOR
No. 23
23
OR
23 37
OR
24 23

23
DOWN
MAIN
DOWN
LOOP

24
DOWN
LOOP
DOWN
SIDINGS

25
DOWN
SIDINGS
TO
DOWN
MAIN
STARTING
23 24

26
DISC
AT
No. 23
NIL
OR
38

27
DISC
FOR
No. 28
28

28 *
UP
MAIN
SHELL MEX
AND
B P
SIDING

29
DISC
FOR
No. 28
28

30
UP
LOOP
TO
SAND
DRAG
FACING
UP
MAIN

31
DISC
FOR
No. 30
30
OR
30 19

35 *
DISC
AT 42B

36
DISC
FOR
DOWN
SIDINGS
39 37

37
DISC
FOR
No. 41
41 38

38
DISC
FOR
No. 42
42

39
DOWN
LOOP
FACING
DOWN
SIDINGS

40
FPL
FOR
No. 41
NIL
OR
41

41
DOWN
MAIN
FACING
DOWN
LOOP

42 *
MAIN
+ OVER

43
DISC
FOR
No. 42
42 41 40 39
OR
42 41 40
OR
23 42 41 40

44
DISC
FOR
No. 42
40 42

45
BACK
LOCK
FOR
BRIDGE
WEST
SWITCH
LEVER

46
DOWN
MAIN
DETONATORS
OFF
ON

50
DOWN
MAIN
TO
SIDINGS
HOME
41 40 39
OR
23 41 40 39

51
DOWN
MAIN
ADVANCED
STARTING
(SLOT)
LINE
CLEAR

52
DOWN
LOOP
TO
DOWN
MAIN
STARTING
23

53
DOWN
MAIN
TO
DOWN
LOOP
HOME
41 40
OR

54
DOWN
MAIN
STARTING

55
DOWN
MAIN
HOME
40

* = REPLACEMENTS
ALL IVORINES

23 41 40

HAVERFORDWEST STATION

52067/7/ 2