

1
DOWN
MAIN
DISTANT
30
6
2

2
DOWN
MAIN
HOME
30

3
DOWN
MAIN
DETONATORS
OFF
ON

5
UP
BRANCH
TO
DOWN
MAIN
HOME
29

6
DOWN
MAIN
STARTING

7
DOWN
MAIN
TO
UP
BRANCH
HOME
31
35
36
30

8
UP
BRANCH
HOME
29
31
34
35
36

10
UP
BRANCH
STARTING
12
OR
42

12
UP
BRANCH
ADVANCED
STARTING

16
DISC
FOR
17
17
OR
17
19

17
UP
MAIN
UP
SIDINGS

18
DISC
FOR
17
17

19
COMPOUND
POINTS
IN UP
SIDINGS
17

20
DISC
FOR
19
17
19

23
DISC
FOR 24
30
24
OR
31
35
36
30
24

24
MAIN
+ OVER

25
DISC
FOR 24
24

26
DISC
FOR 28
29
28

27
DISC
FOR 28
29
28
31
34
35
36

28
BRANCH
BRANCH
SIDING
29

29
UP
BRANCH
SAFETY
FACING
DOWN
MAIN

30
F.P.L.
FOR 31

31
MAIN
* OVER
(FACING)

32
F.P.L.
FOR 31

34
COMPOUND
POINTS
IN
DOWN
MAIN
BRANCH
29
31

35
DOWN
BRANCH
SAFETY
FACING
UP
MAIN

36
COMPOUND
POINTS
IN UP
MAIN
BRANCH
31
35

37
DISC
FOR 28
29
28

39
UP
SIDINGS
TO UP
BRANCH
STARTING
12
41
40
OR
42
41
40

40
COMPOUND
POINTS
IN
DOWN
BRANCH
UP
BRANCH

41
DOWN
BRANCH
FACING
UP
SIDING

42
UP
BRANCH
SAFETY
[SPRING
SLOTTED]

43
DISC
FOR 42
42
41
40

44
UP
BRANCH
AND DOWN
BRANCH
SAFETY
FACINGS
DOWN
BRANCH

45
DOWN
BRANCH
TO
BRANCH
SIDING
STARTING

46
DOWN
BRANCH
STARTING
29
31
34
35
36

47
DOWN
BRANCH
TO
DOWN
MAIN
STARTING
(BACKING)
31
35
36

48
DISC
FOR 42
42

49
INTERLOCKING
LEVER
FOR
BUSH
COLLIERY
GROUND
FRAME

50
DOWN
BRANCH
TO UP
SIDINGS
HOME
41
44

53
UP
MAIN
TO
DOWN
BRANCH
HOME
29
31
32
34

54
UP
MAIN
SHUNT

55
UP
MAIN
STARTING

56
DOWN
BRANCH
TO UP
MAIN
STARTING
35

57
DOWN
BRANCH
HOME
44

60
UP
MAIN
HOME
32

61
UP
MAIN
DISTANT
32
55
60

NEW SET OF IVORINES
INSP. COCKSBDGE NEWPORT
12.4.1944

54
DOWN
BRANCH
TO
UP
MAIN
CALLING
ON
35

17.1.1952

11
UP
BRANCH
CALLING
ON

12
UP
BRANCH
ADV'D
START'G

9.5.1926 (?)
INSP. JENKINS
QNo 7492

15
DISC
AT
No. 34
26
32
OR
26
30
34
38
43
42

45
DISC
FOR
No. 43
43
OR
41
43
44

46
F.P.L.
FOR
No. 41
NIL
OR
41

50
DOWN
BRANCH
TO
SIDINGS
HOME
41
46

51
DOWN
BRANCH
ADV'CD
START'G
26

52
DOWN
BRANCH
START'G
26
30
34
35
38

53
UP
MAIN
TO
DOWN
BRANCH
HOME
26
30
34
35
OR
26
30
34
35
41
43
44

56
DOWN
BRANCH
TO UP
MAIN
START'G
35
38

57
DOWN
BRANCH
TO UP
MAIN
HOME
35
38
46

58
DOWN
BRANCH
HOME
26
30
34
35
38
46

60
UP
MAIN
HOME
35
OR
35
41
43
44

61
UP
MAIN
DISTANT
35
55
60
OR
35
41
43
44
55
60

REQUIRED WITH LOCKING
INSP. JENKINS NEWPORT
24. 11. 1926

PENAR JCN

51266/7/4