


DOWLAIS JUNCTION

SPARE : 9

SPACES : 4. 5. 6. 7. 24

MCK & H C&T 4" (GW LOCKING)



FURNACE TOP G.F.
2 LEVERS WORKING POINTS 'X'
K.R.I.

INTERLOCKING LEVER NO 22

