

# DOWLAIS JUNCTION

<u>1</u> DOWN MAIN HOME	<u>2</u> DOWN BRANCH TO DOWN MAIN HOME	* <u>3</u> DOWN BRANCH TO DOWN MAIN STARTING	<u>8</u> DOWN MAIN DETONATORS — OFF ON	<u>9</u> INTERLOCKING WITH WASHERY SIDING G.F.
	<u>13</u> 12 10	<u>13</u> 12 10		

* <u>10</u> DOWN BRANCH AND DOWN SIDING TO STEEL WORKS FACING — TO DOWN MAIN	<u>11</u> COMPOUND POINTS TO UP MAIN	<u>12</u> DOWN MAIN — DOWN BRANCH	<u>13</u> UP MAIN FACING — UP BRANCH	* <u>14</u> DOWN BRANCH SIDING TO STEEL WORKS STARTING (DISC)
<u>13</u> 12	<u>13</u> 12	<u>13</u>		<u>17</u>

* <u>15</u> DOWN BRANCH TO STEEL WORKS STARTING (DISC)	* <u>16</u> STEEL WORKS FROM DOWN BRANCH SIDING	* <u>17</u> UP BRANCH FACING — DOWN BRANCH SIDING	* <u>18</u> FROM STEEL WORKS TO DOWN BRANCH SIDING STARTING (DISC)	* <u>19</u> UP BRANCH FROM STEEL WORKS
<u>17</u> 16	FROM DOWN BRANCH		<u>17</u>	UP BRANCH — 13

# DOWLAIS JUNCTION

<p>✕</p> <p><u>20</u></p> <p>FROM STEEL WORKS TO UP BRANCH STARTING (DISC)</p>	<p><u>21</u></p> <p>F.P.L. FOR NO 13 — NIL — OR 13</p>	<p>✕</p> <p><u>22</u></p> <p>INTERLOCKING WITH FURNACE TOP C.F.</p>	<p>✕</p> <p><u>23</u></p> <p>UP MAIN DETONATORS — OFF ON</p>	
<p>✕</p> <p><u>25</u></p> <p>UP MAIN TO DOWN BRANCH SIDING HOME — 13 17 19 21</p>	<p><u>26</u></p> <p>UP BRANCH STARTING</p>	<p>✕</p> <p><u>27</u></p> <p>UP MAIN TO UP BRANCH HOME — 13 19 21</p>	<p><u>28</u></p> <p>UP MAIN STARTING — LINE CLEAR</p>	<p><u>29</u></p> <p>UP MAIN HOME — 21</p>

✕ 13 LEADS MARKED. IVORINES WITH CASTINGS ORDER NO. 22/8324

MR. NORRIS

TREFOREST

8. AUG 1952