

1  
DOWN  
MAIN  
DISTANTS  
6  
3  
2

2  
DOWN  
MAIN  
HOME  
10

3  
DOWN  
MAIN  
INNER  
HOME

4  
DOWN  
BRANCH  
HOME

5  
DOWN  
BRANCH  
TO  
DOWN  
MAIN  
INNER  
HOME  
48

6  
DOWN  
MAIN  
STARTING  
LINE  
CLEAR

7  
DOWN  
MAIN  
TO  
DOWN  
SIDING  
HOME  
11  
10

8  
DISC  
FOR 9  
11  
10  
9  
OR  
10  
9

9  
MAIN  
+ OVER

10  
F.P.L.  
FOR 11

11  
DOWN  
MAIN  
FACING  
DOWN  
SIDING

12  
DISC  
FOR 9  
9

13  
DISC  
FOR 11  
11  
12

14  
DOWN  
SIDINGS  
TO MAIN  
OR DOWN  
SIDING  
STARTINGS  
(SELECTED)

15  
DOWN  
MAIN  
DOWN  
SIDINGS

NIL  
OR  
17  
OR  
15

16  
DISC  
FOR 15  
15

17  
DISC  
FOR 18  
18

18  
DOWN  
MAIN  
DOWN  
SIDING

19  
DISC  
FOR 18  
18

20  
DISC  
FOR 21  
21

21  
UP  
BRANCH  
UP  
SIDING

22  
UP  
SIDING  
TO  
SPUR  
STARTING

23  
UP  
SIDING  
TO  
UP  
BRANCH  
STARTING  
21

24  
DISC  
FOR 26  
26  
OR  
26  
25

25  
COMPOUND  
POINTS  
IN UP  
GOODS  
LOOP

26  
UP  
GOODS  
LOOP  
FACING  
UP  
BRANCH

27  
UP  
SIDINGS  
TO UP  
BRANCH  
STARTING  
25  
26

28  
DISC  
FOR 29  
29

29  
BRANCH  
+ OVER

30  
DISC  
FOR 29  
29

31  
DISCS  
FOR 34  
(SELECTED)  
33  
OR  
32

32  
UP  
GOODS  
LOOP  
FACING  
UP  
MAIN  
34

33  
SAFETY  
POINTS  
IN  
MIDDLE  
SIDING  
34

34  
UP  
MAIN  
FROM  
UP  
GOODS  
LOOP  
OR  
MIDDLE  
SIDING

35  
DISC  
FOR 33  
33

36  
DISC  
FOR 38  
37  
OR  
38

37  
DISC  
FOR 39  
38

38  
SPUR  
TO UP  
SIDING  
UP  
SIDINGS

39  
SPUR  
TO UP  
SIDINGS  
UP  
GOODS  
LOOP  
38

40  
UP  
MAIN  
FACING  
UP  
GOODS  
LOOP

41  
F.P.L.  
FOR 40

42  
UP  
GOODS  
LOOP  
TO  
UP  
MAIN  
STARTING  
32

43  
UP  
GOODS  
LOOP  
TO  
UP  
BRANCH  
STARTING  
26

44  
UP  
SIDINGS  
TO  
SPUR  
STARTING  
38

45  
UP  
GOODS  
LOOP  
TO  
SPUR  
STARTING  
39

46  
UP  
MAIN  
TO UP  
GOODS  
LOOP  
INTERMEDIATE  
HOME  
40  
41

47  
DISC  
FOR 52  
52

48  
DOWN  
MAIN  
FROM  
DOWN  
BRANCH  
50

49  
SAFETY  
POINTS  
IN UP  
BRANCH  
50

50  
UP  
MAIN  
FACING  
UP  
BRANCH

51  
F.P.L.  
FOR 50

52  
MAIN  
+ OVER

53  
DISC  
FOR 52  
49  
51  
52  
02  
51  
52

54  
UP  
BRANCH  
CALLING  
ON

55  
UP  
BRANCH  
STARTING  
LINE  
CLEAR

56  
UP  
MAIN  
TO UP  
BRANCH  
INNER  
HOME  
49  
51

57  
UP  
MAIN  
CALLING  
ON

58  
UP  
MAIN  
STARTING  
LINE  
CLEAR

59  
UP  
MAIN  
INNER  
HOME  
51

60  
UP  
MAIN  
INTERMEDIATE  
HOME  
41  
51

61  
UP  
MAIN  
HOME  
41

62  
UP  
MAIN  
DISTANT  
58  
59  
60  
61

INSPR. WILLIAMS  
WORCESTER  
85/7617

48  
DOWN  
MAIN  
FROM  
DOWN  
BRANCH  
49

49  
UP  
MAIN  
FACING  
UP  
BRANCH

50  
SAFETY  
POINTS  
IN UP  
BRANCH  
49

51  
F.P.L.  
FOR 49

53  
DISC  
FOR 52  
50  
51  
52  
OR  
51  
52

56  
UP  
MAIN  
TO UP  
BRANCH  
INNER  
HOME  
50  
51

(RENUMBERING OF JUNCTION)

46  
UP  
MAIN  
TO UP  
GOODS  
LOOP  
HOME  
40

60  
UP  
MAIN  
HOME  
51

62  
UP  
MAIN  
DISTANT  
58  
59  
60

(EXTENSION OF LOOP)

HONEYBOURNE STATION NORTH

S2583/7/4

27  
UP  
SIDINGS  
TO UP  
BRANCH  
OR  
SPUR  
STARTINGS  
(SELECTED)  
25  
26  
OR  
38

41  
DISC  
FOR 42  
42

42  
UP  
GOODS  
LOOP  
DEPOT  
SIDING

43  
UP  
GOODS  
LOOP  
TO  
SPUR  
OR UP  
BRANCH  
STARTINGS  
(SELECTED)  
39  
OR  
26

44  
UP  
GOODS  
LOOP  
TO UP  
MAIN  
STARTING  
32

45  
DEPOT  
SIDING  
TO UP  
GOODS  
LOOP  
STARTING  
42

62  
UP  
MAIN  
DISTANTS  
58  
59  
60

(OPENING OF SHEEN HILL)

46  
DISC  
FOR 50  
50  
OR  
50  
47

61  
UP  
MAIN  
TO  
GOODS  
LOOP  
HOME  
40

(FOR WORK ON 13.8.44)

36  
DISC  
AT  
38  
NIL  
OR  
37

37  
DISC  
AT  
39  
38  
OR  
39

MR. ABEL  
15.7.52  
(DISCS REROUTED)

24  
DISC  
FOR 26  
26

36  
DISC  
AT  
38  
NIL  
OR  
38

43  
UP  
GOODS  
LOOP  
TO  
SPUR  
OR UP  
BRANCH  
STARTINGS  
(SELECTED)  
38  
OR  
26

20.8.1956  
(ALTERATIONS TO)  
UP SIDINGS