

1
DOWN
MAIN
DISTANT
15

2
DOWN
MAIN
HOME
11
5

3
DOWN
MAIN
STARTING
11
5

4
DOWN
MAIN
TO
SIDINGS
STARTING
9
11

5
FPL
FOR
6

6
DOWN
MAIN
FACING
UP
MAIN

7
MAIN
AND
FPL
TO
CROSS

8
SIDING
UP
MAIN
7

9
SPUR
FROM
DOWN
MAIN

10
DISC
FOR
9
9

11
FPL
FOR
12

12
MAIN
FACING
DOWN
MAIN

13
FPL
FOR
12

14
SWITCH
LEVER
NOTCH
1 TO 2
LOCAL KEY
6
5
11
13
NOTCH
2 TO 3
1
18

15
DOWN
MAIN
HOME
AND
STARTING
WHEN
SWITCHED
OUT
14
NOTCH 2

16
UP
MAIN
STARTING
6

17
UP
MAIN
HOME
13

18
UP
MAIN
DISTANT
[14
NOTCH 2]
16
17

IVORINES & CASTINGS

INSP. EDWARDS, OSWESTRY 50/2972
1948 ?

ERWOOD

S3210/7