

2
UP
AND
DOWN
PLATFORM
LINE
UP
STARTING
69

37
F.P.L.
FOR
No. 36
29
36
40
62
29
36
39
40

89
FROM
DOWN
MAIN
TO
CREWE
CALLING
ON
65

4
UP
MAIN
TO
UP
PLATFORM
LINE
HOME
34
31
29
28

90
UP &
DOWN
PLATFORM
LINE
TO
CREWE
CALLING
ON
65
68
73
74
OR
64
65
68
73
74

5
UP
AND
DOWN
PLATFORM
LINE
CALLING ON
OR
WARNING
(SELECTED)
69
OR
STAT
OCCUPIED

86
DISC
AT
No. 71
73
75
SB 100
OR
73
75
106 AT
OCCUPIED

91
SLOTING
LEVER
92

6
UP
MAIN
TO
UP
PLATFORM
LINE
INNER
HOME
34
31

87
DISC
AT
No. 71
73
69
67

7
UP
MAIN
TO
UP
PLATFORM
LINE
CALLING ON
OR
WARNING
(SELECTED)
34
31

88
FROM
DOWN
MAIN
TO
L&NW
LOOP
START'G
64
65

93
FROM
DOWN
MAIN
TO
CREWE
START'G
65

37.
88.89.90.93
BRASSES

CREWE JCN

99
 UP &
 DOWN
 PLATF'M
 LINE
 TO
 CREWE
 CALLING
ON
 65
 68
 73
 74
OR
 64
 65
 68
 73
 74

106
 DOWN
 MAIN
 HOME
 -
 47
 76

107 *
 UP &
 DOWN
 PLATF'M
 TO
 L&NW
 LOOP
 START'G
 64
 65
 67
 68

108
 BACKING
 FROM
 DOWN
 SIDING
 TO
 HORSE
 LANDING
 (DISC)

* BRASS

CREWE JCN	

110 *
 DOWN
 MAIN
 PLATFIM
 LINE
 TO
 CREWE
 CALLING
ON
65
 71
 72

114 *
 DOWN
 MAIN
 PLATF'M
 LINE
 TO
 CREWE
 START'G
65
 71
 72

22 *
 DISC
 FOR
 No. 41
42
 41
 108

25 *
 UP
 AVOID'G
 LINE
 TO
 MAIN
 START'G
 (DISC)
31
 27
26
28
 32
 31
 27
 26

* BRASS

CREWE JCN

S 2951/7/