

ALTERATIONS TO SIGNALLING AND PERMANENT WAY

between

WICKFORD and SOUTHMINSTER

MONDAY 30 NOVEMBER 1992

DRIVERS TO KEEP A GOOD LOOK-OUT FOR HANDSIGNALS

The control of the area from Southminster to the London side of Wickford station, including signals on the Up and Down Southend Lines, as depicted on the enclosed diagram, will be transferred from Wickford signal box to Liverpool Street (L) signal box. All new signal telephones will communicate with Liverpool Street signal box.

Wickford signal box will remain and supervise Down Line automatic signals DS22, DS22B, DS23, DS24, DS25, DS25B, DS26 and DS27 located between Mountnessing Junction and Wickford.

SIGNALLING RECORD SOCIETY

<u>www.s-r-s.org.uk</u> DIGITAL ARCHIVE

This PDF Copy has been provided free of charge by David Allen in order to assist your research into UK signalling.

This file is one of a number scanned by David Allen using material from his own collection and from the collections of Phil Deaves, Robert Dey, David Ingham, Simon Lowe, John McCrickard, John Midcalf, Roger Newman, Richard Pulleyn and Chris Wolstenholmes. Thank you one and all. Many of the original documents are now in the SRS Archive or at the National Railway Museum.

You may also like to provide copies of Signalling Notices and Weekly (and periodical) Operating Notices as scans or as originals. The SRS is always willing to accept donations of any signalling or signalling related material for inclusion in the Society's Archive. Please contact the Archivist in the first instance.

For a list of PDFs currently available visit the list of <u>Weekly</u> Notices or <u>Signalling</u> Notices page.

If you have benefited from this PDF copy, why not join the Signalling Record Society and receive support for your researches and access to the Society's Archives


Members receive "The Signalling Record" six times annually plus a newsletter and have the opportunity to purchase SRS <u>books</u> and other <u>publications</u> at a discount. They also have access to back issues of The Newsletter and The Signalling Record which are only available to members. These contain a wealth of information accumulated since 1970, much of which is not readily available anywhere else.


In addition, Members have the opportunity to join signalling related visits to locations on the UK national and London Underground systems; and to other UK Railways.

To join the Signalling Record Society visit

www.s-r-s.org.uk/membform.html

SIGNAL APPLICATIONS			
Signal No.	Aspect	Indication	Application
L549	Main		Down Southend
	Main	Pos.4	Up Southend
L551	Main		Up Southend
	Subsidiary		Up Siding
L553	Main	Pos.2	Down Southminster
	Main	Pos.1	Down Southend
	Main		NOT IN USE
L555	Main	'B'	Down Southminster
	Main	'M'	Down Southend
L557	Main	'B'	Down Southminster
	Main	'M'	Down Southend
L559	Main	Pos.1	Down Southminster
	Main		Down Southend
L592	Main		Up Southend
	Main	Pos.4	NOT IN USE
L594	Main		NOT IN USE
	Position Light		Down Siding
L596	Main	'ט'	Up Bay
	Main	'м'	Up Southend
	Main	'x'	Down Southend
	Main	'D'	Down Bay
L604	Main	'ט'	Up Bay
	Main		Up Southend
5150	Position Light	'ט'	Up Bay
	Position Light	'M'	Up Southend
	Position Light	'x'	Down Southend
	Position Light	'D'	Down Bay
5157	Position Light		Spur
	Position Light		Down Southend





- -