

ABERBEEG JUNCTION

LEVEL 2 PLATE DESCRIPTIONS - 9th April 1960 (A.V. Davis)

R.Jc.

* 5	* 6	* 7	* 9	* 10	* 11	* 12	* 13	* 14	15	* 16
DOWN C'BRKV'LE SDGS HOME SHUNT SIG AG5	DOWN C'BRKV'LE SDGS INNER HOME TO MAIN SHUNT SIG AG6 <u>AG6</u> 23, 21	DOWN C'BRKV'LE SDGS INNER HOME TO SDGS SHUNT SIG AG6 <u>AG6</u> 24 23 21	DOWN MAIN HOME SIGNAL AG9	DOWN MAIN SIGNAL AG10 <u>16</u>	DOWN MAIN SIGNAL AG11	DOWN MAIN TO DOWN LOOP SIGNAL AG10 <u>25</u> 16	DOWN LOOP TO DOWN MAIN SIGNAL AG13	DOWN MAIN TO DOWN SIDINGS SIGNAL AG10 <u>24</u> 16	DISC	DOWN MAIN TO DOWN SIDINGS OR DOWN LOOP OR ALONG DOWN MAIN GROUND SIGNAL AG16/23
17	18	19	20	21	22	23	24	25	26	27
DISC AT <u>25B</u> 25 31 OR 20	DISC FOR <u>24B</u> 24 31	DOWN C'BRKV'LE SIDINGS INNER HOME TO LOOP SHUNT SIGNAL AG6 <u>20</u> *	DOWN LOOP SAFETY	DOWN C'BRKV'LE SIDINGS TO DOWN MAIN <u>22</u>	DOWN MAIN TO DOWN C'BRKV'LE SIDINGS	FPL FOR 25A	DOWN SIDINGS DOWN MAIN <u>25</u>	DOWN MAIN FACING DOWN LOOP	UP MAIN FACING TO UP C'BRKV'LE SIDINGS SIGNAL AG61 <u>26</u> 28 *	FROM UP SIDING UP MAIN * *

* Short lever

* lever incorrectly
* labelled for
current use

[No. 27 was then up
main safety of point]

ABERBEEG JUNCTION (Contd)

28	29	30	31	32	33	34	35	36	37	38
FPL FOR 26	UP MAIN TO UP C'BRK'LE SIDINGS SIGNAL AG 61 26 28	MAIN X OVER	DISC AT 22 NIL OR 22 21	DISC AT 30B 27 28 30 OR 26 28 30 OR 31		INTERLOCK'G LEVER WITH SIX BELLS COLLY GROUND FRAME * +	DOWN C'BRK'LE SIDINGS FROM UP C'BRK'LE SIDINGS * +	DISC AT 37 26 49 OR 38	UP C'BRK'LE SIDINGS UP SIDINGS 44	UP SIDINGS TO UP C'BRK'LE SIDINGS 37

* Short lever
+ Blue (top) / blown
≠ Out of use
* Lever incorrectly
* labelled for
current use

39	40	41	42	43	44	45	46	47	48	49
SIDINGS 1-4 ST'ING TO UP C'BRK'LE SIDINGS 38	SIDINGS 1-4 ST'ING FOR UP SIDING	DISC AT 27 27 49 OR 43 42	DISC AT 44	UP SIDING TO UP MAIN	UP SIDING TO SIDINGS 5-10	DISC SIDINGS 5-10 STARTING TO UP SIDING 44	DISC SIDINGS 5-10 START'G TO UP MAIN 43 44	SIDINGS 1-4 START'G TO UP MAIN 43	UP SIDING FROM UP LOOP	DISC AT 50A 26 OR 27
≠	≠	* *	≠	≠	≠	≠	≠	≠	≠	

ABERBEEG JUNCTION (Contd)

Rtc (3)

50	51	52	53	54	55	56	57	58	59	60	61	62
UP MAIN UP LOOP	DISC UP LOOP HOME TO UP C'BRKV'LE SIDINGS	DISC UP LOOP HOME TO UP SIDING	INT'LOK'g LEVER FOR L'HILLETH COLLY INLET GF	UP MAIN FACING UP LOOP	UP MAIN TO L'HILLETH COLLY SIGNAL AG 62 54 (slotted)		UP C'BRKV'LE SIDINGS START'g 35	UP MAIN SIGNAL AG 58	UP LOOP HOME TO UP MAIN	UP MAIN TO UP LOOP SIGNAL AG 62	UP MAIN SIGNAL AG 61 27 28	UP MAIN HOME SIGNAL AG 62 * * *
	26 28 50	48 ‡	* ‡	*	* ‡			* ‡	43 48 OR 27 28 50	54 *	* *	* *

* Short Lever

‡ Out of use