

TAVISTOCK JUNCTION — BRASS PLATE c1895

1	2	3	4	5	6	7	8		
DOWN DISTANT FROM BRANCH — 10 9 5 2	DOWN HOME FROM BRANCH — 10 9	DOWN MAIN DISTANT — 5 4	DOWN MAIN HOME	DOWN STARTING	DOWN MAIN — FROM DOWN SIDING	DOWN REFUGE SIDING STARTING — 6	MAIN +OVER — 11 OR 11 10		
9	10	11	12	13	14	15	16	17	
DOWN MAIN — FROM BRANCH — 10	UP MAIN FACING — TO BRANCH	No. 10 POINTS UNLOCKED — LOCKED — NIL OR 10	UP MAIN STARTING	UP MAIN HOME — 11	UP MAIN DISTANT — 11 12 13	UP MAIN TO BRANCH STARTING (SLOT)	UP MAIN TO BRANCH HOME — 10 11	UP MAIN TO BRANCH DISTANT — 10 11 15 16	

TAVISTOCK JUNCTION LEVER LEADS 1946

1	2	3	4	5	6	7	8	
DOWN MAIN DISTANTS — 8 7 4 3 2	DOWN MAIN HOME — 37	DOWN MAIN INNER HOME — 37	DOWN MAIN STARTING — NIL OR 85 49	UP BRANCH TO DOWN MAIN HOME — 54 53 OR 85 54 53 49	DISC FOR 84 — 84 7 OR 84 9	DOWN MAIN ADVANCED STARTING	DOWN MAIN OUTER ADVANCED STARTING — LINE CLEAR	
9	11	12	13	14	17	18	19	20
DOWN MAIN TO UP & DOWN GOODS RUNNING LOOP ADVANCED STARTING — 85 49	DOWN MAIN TO DOWN GOODS LOOP HOME — 23	DOWN MAIN TO DOWN SIDINGS HOME — 24 23	DOWN MAIN TO DOWN GOODS LOOP INNER HOME — 39 38 37	DOWN MAIN TO DOWN SIDINGS INNER HOME — 39 38 37	DOWN MAIN DETONATORS OFF — ON	DOWN GOODS RUNNING LOOP HOME	DOWN GOODS RUNNING LOOP TO DOWN SIDINGS HOME — 24	DOWN GOODS LOOP INNER HOME — 25
21	22	23	24	25	26	27	28	30
DOWN GOODS LOOP TO DOWN SIDINGS INNER HOME — 39	DOWN SIDINGS HOME —	DOWN MAIN FACING — DOWN SIDINGS	DOWN GOODS LOOP FACING — DOWN SIDINGS	DOWN GOODS LOOP SAFETY	DISC FOR 23 — 23	DISC AT 65 — 28 OR 54 OR 54 6	DISC FOR 36 — 37 36	DOWN SIDINGS STARTING
31	32	33	34	35	36	37	38	39
DOWN SIDINGS TO DOWN GOODS LOOP STARTING — 40	DOWN SIDINGS TO NO. 2 SPUR STARTING	DOWN SIDINGS TO NO. 1 SPUR OR DOWN MAIN STARTING — 42 OR 42 35	DOWN GOODS LOOP TO NO. 1 SPUR OR DOWN MAIN — 42 OR 35	DOWN GOODS LOOP TO DOWN MAIN STARTING — 85 49 43 OR 43	MAINS + OVER	F.P.L. FOR 38	DOWN MAIN FACING — DOWN GOODS LOOP	DOWN GOODS LOOP — DOWN SIDINGS —

40	41	42	43	44	45	46	47	
DOWN GOODS LOOP — DOWN SIDINGS	DISC FOR 40 — 40	DOWN GOODS LOOP — DOWN SIDINGS	DOWN MAIN — DOWN GOODS LOOP	DISC FOR 36 — 36	DISC FOR 38 — 38 OR 38 44	DISC AT 38 — 25 26 OR 25	DISC FOR 39 — 39 45 OR 39 46	
48	49	51	53	54	55	56	61	20
DISC FOR 42 — 42	INTERLKG LEVER FOR UP & DOWN GOODS RUNNING LOOP	DISC FOR 43 — NIL OR 44 OR OR 43 43 OR 45 43 OR 41 25 OR 43 43 48	F.P.L. FOR 55 — NIL OR 54	F.P.L. FOR 56	UP BRANCH FACING — DOWN MAIN — 56	MOVEABLE ELBOWS IN UP BRANCH	DISC FOR 65 — 65 OR 65 64	DOWN GOODS LOOP INNER HOME — 25
63	64	67	68	69	70	72	73	30
DISC AT 66 — NIL OR 72	DISC FOR 66 — 66	UP GOODS LOOP TO UP MAIN OUTER ADVANCED STARTING — 65	UP GOODS LOOP TO UP GOODS RUNNING LOOP OUTER ADVANCED STARTING	DISC FOR 66 — 66	DISC FOR 73 — 73 72 OR 72	DISC FOR 77 — 77 54 6 OR 77	UP GOODS LOOP — UP SIDINGS	DOWN SIDINGS STARTING —
74	75	77	78	79	80	81	82	39
UP GOODS LOOP TO UP SIDINGS STARTING — 73	SPUR TO UP GOODS LOOP STARTING	UP MAIN FACING — UP GOODS LOOP	UP GOODS LOOP ADVANCED STARTING	UP GOODS LOOP STARTING	F.P.L. FOR 77	F.P.L. FOR 56 — 56	UP MAIN FACING — DOWN BRANCH	DOWN GOODS LOOP — DOWN SIDINGS —

TAVISTOCK JUNCTION LEVER LEADS 1946 Sheet 3

83	84	85	86	87	88	89	90
F.P.L. FOR 82 — 82 OR 81	MAIN +OVER	DOWN MAIN FACING — UP & DOWN GOODS RUNNING LOOP	DISC FOR 77 — 77	DISC AT 77	UP MAIN TO UP GOODS LOOP INNER HOME — 83 86	DISC FOR 84 — 83 84	DISC AT 84
91	92	96	97	98	99	100	101
UP & DOWN GOODS RUNNING LOOP TO DOWN SIDINGS HOME — 43 51 85 90	UP MAIN DETONATORS — OFF — ON	UP MAIN DRAW AHEAD	UP MAIN DRAW AHEAD	UP MAIN TO DOWN BRANCH INNER HOME — 82 83	UP MAIN OUTER ADVANCED STARTING — LINE CLEAR	UP MAIN ADVANCED STARTING	UP MAIN STARTING
102	103	104	105				
UP MAIN INNER HOME — 83 87	UP & DOWN GOODS RUNNING LOOP TO UP MAIN HOME — 83 84 85 89	UP MAIN HOME — 83	UP MAIN DISTANTS — 99 100 101 102 104				