

TONDU - Lever Plate Descriptions - 9th July 1986

Rtc.

2 UP MAIN HOME <u>27</u> 17 <u>OR</u> 30 28 27 17	3 UP MAIN INNER HOME <u>27</u>	4 FROM BLAENGARW HOME TO UP MAIN <u>27</u> 20	5 FROM NANTYMOEL HOME TO UP MAIN <u>27</u> 20 18	6 UP MAIN START'G (Line Clear) *		9 UP MAIN INNER HOME TO DOWN BRANCH <u>31</u> 31 30 28 27 28 27	10 FROM BLAENGARW HOME TO DOWN BRANCH <u>31</u> 30 28 27 20	11 FROM NANTYM'L HOME TO DOWN BRANCH <u>31</u> 30 28 27 20 18	12 DOWN BRANCH START'G <u>30</u>	13 DOWN BRANCH ADVANCED START'G <u>50</u>	14 DOWN BRANCH OUTER ADVANCED START'G	
16 INTERLKG LEVER WITH TONDU NORTH G.F. [BLUE/ BROWN] *	-17 MAIN SINGLE LINE SAFETY [BLUE/ BLACK] *	18 DOWN BLAENGARW BRANCH FACING FROM UP NANTYMOEL BRANCH <u>21</u>	19 F.P.L. FOR 18	20 F.P.L. FOR <u>21</u> 21	21 OGMORE BRANCH SAFETY FACING <u>23</u>	22 DOWN OGMORE BRANCH FACING REFUGE SIDING <u>23</u>	23 DOWN MAIN FACING REFUGE SIDING OR OGMORE BRANCH	24 F.P.L'S FOR 22A AND 23	25 DISC FOR 22 B <u>27</u> 22 <u>OR</u> 31 30 28 27 22	26 27 F.P.L. FOR 28A	28 UP MAIN FACING BRANCH	29 F.P.L. FOR 28B
												* = Short Lever

TONDU (Contd.)

30	31		33		45	46	47	48	49	50	51	52
F.P.L. FOR 31	DOWN BLAENGARW TO UP BRANCH FACING DOWN BRANCH		DISC DOWN MAIN INNER HOME TO REFUGE SIDING 22 24		DISC FOR 46 31 30 46	RUNAWAY SIDING SAFETY	DISC BACKING FROM DOWN BRANCH 29 22 31 31 46 OR OR 18 24 19 28 24 29 28 31 29 OR 31	INTER'LKG LEVER WITH BRANCH GROUND FRAME FOR BAY SIDING ← [BLUE/BROWN] → *	INTER'LKG LEVER WITH BRANCH GROUND FRAME FOR BALLAST AND COMPOUND SIDINGS * *	UP BRANCH FACING FROM DOWN BRANCH [BLUE/ BLACK] *	DISC AT 50 29 OR 46 24 OR 28 24 29 28 31 29 50 OR OR 22 22 24 24 28 28 29 29 OR 31 18 50 19 OR	BRANCH DETONATOR OFF ON
53	54	55	56	57	58	59	60	61	62	63		64
MAIN DETONATOR OFF ON	DISC BACKING ALONG UP BRANCH	UP BRANCH INNER HOME TO NANTYMOEL 18 19 24 28 29	DISC UP BLAENG'W INNER HOME TO RUNAWAY SIDING OR REFUGE SIDING 29 46 OR 22 24 28 29	DOWN MAIN START'g	UP BRANCH INNER HOME TO BLAENGARW 19 21 24 28 29	UP BRANCH INNER HOME TO DOWN MAIN 24 28 29	UP BRANCH HOME 51	DOWN MAIN INNER HOME TO NANTYMOEL 18 19 24	DOWN MAIN INNER HOME TO BLAENGARW 19 21 24	DOWN MAIN INNER HOME 24 28 29 31 31 46 50	65 ACCEPTANCE LEVER [BLUE/ BROWN]	DOWN MAIN HOME 24 OR 19 21 24 OR 18 19 24 * = Shift Lever