

# SPECIAL NOTICE PERMANENT WAY AND SIGNALLING ARRANGEMENTS J. M:DCAL®

MOTHERWELL
SIGNALLING CENTRE
RESIGNALLING
STAGE 7

(THIS NOTICE NEED NOT BE ACKNOWLEDGED)

## SIGNALLING RECORD SOCIETY

# www.s-r-s.org.uk

This PDF Copy has been provided free of charge by David Allen in order to assist your research into UK signalling.

This file is one of a number scanned by David Allen using material from his own collection and from the collections of Phil Deaves, Robert Dey, David Ingham, Simon Lowe, John McCrickard, John Midcalf, Roger Newman, Richard Pulleyn and Chris Wolstenholmes. Thank you one and all. Many of the original documents are now in the SRS Archive or at the National Railway Museum.

You may also like to provide copies of Signalling Notices and Weekly (and periodical) Operating Notices as scans or as originals. The SRS is always willing to accept donations of any signalling or signalling related material for inclusion in the Society's Archive. Please contact the <u>Archivist</u> in the first instance.

For a list of PDFs currently available visit the list of <u>Weekly</u> Notices or <u>Signalling</u> Notices page.

If you have benefited from this PDF copy, why not join the Signalling Record Society and receive support for your researches and access to the Society's Archives

Members receive "The Signalling Record" six times annually plus a newsletter and have the opportunity to purchase SRS <u>books</u> and other <u>publications</u> at a discount. They also have access to back issues of The Newsletter and The Signalling Record which are only available to members. These contain a wealth of information accumulated since 1970, much of which is not readily available anywhere else.

In addition, Members have the opportunity to join signalling related visits to locations on the UK national and London Underground systems; and to other UK Railways.

To join the Signalling Record Society visit

www.s-r-s.org.uk/membform.html

### MOTHERWELL SIGNALLING CENTRE

### **RESIGNALLING - STAGE 7**

### **OPENING ARRANGEMENTS**

The altered permanent way and signalling arrangements shown on the accompanying diagram and described herein will be brought into use in accordance with details which will be shown in Section B of SW Notice No. 42 and will be introduced at approximately 18 30 on Sunday 21 October, 1973.

### **DESCRIPTION OF SCHEME**

The area of control of Motherwell Signalling Centre will be extended to include the area covered by the undernoted signal boxes which will be dispensed with:—

Holytown Jn.

Ravenscraig No. 2

Wishaw Central

Track Circuit Block working will apply on the Up and Down Shotts lines between Motherwell Signalling Centre and Bellside Jn., and on the Up and Down Holytown lines and Wishaw Connecting line.

All the new permanent way and signalling are as shown on the accompanying diagram.

### SIGNALLING ARRANGEMENTS

The description of the application of all signals shown on the accompanying diagram is as shown herein:—

Signal prefix letter
M

Controlled from

Motherwell Signalling Centre

BJ

Bellside Jn.

Signal numbers shown within brackets on the diagram are controlled from Bellside Jn, the number being for reference purposes only.

Signals M517 and M520 were previously prefixed W and controlled from Wishaw Central box.

Signal M494 was previously prefixed H and controlled from Holytown Jn. box.

The track circuit marker post situated on the Down Holytown line on Mossend East Jn. side of Holytown station will be removed.

Signal	Aspect, main or draw ahead	Route indication, where provided	Application
RUNNING SIGNA	ALS - UP DIRECTION	ATAMAGNA	
Up Holytown			
M346	Main		To M494
M494	Main Main	Junction indicator	To M502 To M496
M502	Main		To M504
M504	Main draw ahead	D 22 32 30 00 24 1	To M512 Towards M506
M512	Main		To M514
M514	Main		To M520
M520	Main		To M524 (Up Holytown)
Up Shotts M496	Main		To BJ12 (acts as Up distant for Bellside Jn.)
BJ12 '	Main		Up home 1
(2)	Main		Up home 2
(3)	miniature arm		To sidings
(7)	Main		Up starting

Signal	Aspect, Main or Draw ahead	Route indication where provided	Application
RUNNING SIGNALS -	- UP DIRECTION — continu	ied	221662.065
Wishaw Connecting li			
M516	Main		To M520
RUNNING SIGNALS -	- DOWN DIRECTION		
Down Holytown			
<b>/</b> 1521	Main		To M517
M517	Main Main	Junction indicator	To M513 To M475
<b>N</b> 513	Main		To M505
M505	Main		To M503
M503	Main		To M499
M499	Main		To M347
M347	Main		To M343 (Down Holytown)
Down Shotts			
(11)	Main		Down distant
(10)	Main (co-acting arms)		Down home
8)	Main		Down starting
M497R	Main		Distant for M497
M497	Main		To M347
Wishaw Connecting I	ine		
M475	Main Main	Junction indicator	To M445 (Down main) To M447 ) (Down
	draw ahead	Junction indicator	Towards M447 goods loop
	draw ahead	DY	Towards M467 thence Down yard
	draw ahead	1	Towards M467 thence No.1 Up goods loop
	draw ahead	2	Towards M467 thence No.2 Up goods loop
	draw ahead	UY	Towards M467 thence Up yard
	Route indication,	and it should be modified	Property and the second second
Signal	where provided	Application	
SHUNTING SIGNALS			
Up Holytown			The beautiful the second
M493			nnection shown 243 on diagram)
W515		Towards M513 or M475	
M519		Towards M515 or Up siding (controlled from Wishaw Central ground frame.	
Down Holytown			No O Works A L.C.
M506		Towards Ravenscraig No.2 Works Arrival line or Departure line or Ore sidings.	
M498	В	Towards M496 Towards M502 (via connection shown 243 on diagram)	

Signal	Route indication, where provided	Application	
SHUNTING SIGNA	ALS — continued		
Up Shotts			
M495		Towards M347	
(6)		Towards Down starting (shown (8) on diagram)	
Down Shotts			
(9)		Towards Up sidings or	
Bellside Jn. Up s	idingo	Up starting (shown (7) on diagram)	
(4)	numgs	Towards Down starting (shown (8) on diagram)	
(5)		Towards Up Shotts Limit of shunt	
Ravenscraig No.2	! Works		
M507,	D	Towards M503	
M509, X M511		Towards Up Holytown Limit of Shunt	

### **GROUND FRAME ARRANGEMENTS**

Ground frames, each electrically controlled from Motherwell Signalling Centre, will be provided as described below:—

Carfin ground frame

A two-lever ground frame to operate the connection between the Down Holytown and the sidings. Trains may shut in.

Wishaw Central ground frame

A three-lever ground frame to operate the connection between the Up Holytown and the sidings together with signal M519 applying to the sidings. Trains may shut in.

### **NOTICE BOARDS**

Ravenscraig No.2 Works - Ore sidings

The notice board is single sided, facing to outgoing trains and worded STOP TELEPHONE FOR INSTRUCTIONS.

### SIGNAL POST SIGNS

Although not shown on the accompanying diagram the following signs are provided, where applicable, in accordance with Regional practice.

With the exception of signal M497R and Bellside Jn. semaphore signals, signal telephones have been provided throughout the scheme.

### A.W.S. EQUIPMENT

A.W.S. track equipment is provided throughout the scheme.

