

29  
DISC  
FOR  
N° 28  
—  
28  
26  
OR  
28

30 #  
UP  
PLATF M  
TO  
CROSS  
28

34 #  
DISC  
FOR  
No. 35  
40  
35  
OR  
41  
40  
35

55  
DOWN  
PLATFORM  
TO  
DOWN  
MAIN  
STARTING  
—  
21

56  
DOWN  
PLATFORM  
INNER  
HOME

57  
DOWN  
MAIN  
TO  
DOWN  
PLATFORM  
INTERMEDIATE  
HOME  
—  
38

# BRASSES

BADMINTON	
	S600/71