

EAST USK - Lever Plate Descriptions (taken 21/8/1980 - A.V.D.)

Rtc.

| | | | | | | | | | | | | |
|---|---|--|--|---|--|--|--|--|--|--|--|--|
| 2 | 3 | 4 | 5 | 10 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 22 |
| DOWN BRANCH HOME | DOWN BRANCH INT'M'DTE HOME | DOWN BRANCH INT'M'DTE HOME TO YARD 15 | DOWN BRANCH INNER HOME 19 18 | DISC AT 14B NIL OR 14 | BRANCH + OVER | DOWN BRANCH FACING TO YARD | DOWN BRANCH INNER HOME TO DOWN SIDINGS OR RECEPTION LINES 32 18 OR 31 18 OR 18 | GROUND SIGNAL BACKING DOWN UP BRANCH TO DOWN SIDINGS OR RECEPTION LINES OR DOWN RELIEF NIL OR OR 31 32 OR 19 | UP BRANCH FACING FROM DOWN BRANCH | INTERLOCKING LEVER WITH N709 POINTS | DISC FOR 14A 14 | DISC FOR 15A + B 15 |
| 23 | 24 | 25 | 29 | 30 | 31 | 32 | 34 | 35 | 36 | 37 | 38 | 39 |
| INTERLOCKING LEVER WITH N704 POINTS | SLOT CONTROL UP RELIEF TO UP BRANCH 23 | SLOT CONTROL UP RELIEF TO UP BRANCH SHUNT 23 | SLOT CONTROL DOWN RELIEF TO DOWN SIDINGS OR RECEPTION LINES 32 30 OR 31 30 OR 30 | INTERLOCKING LEVER WITH N708 POINTS | DOWN BRANCH FACING RECEPTION NO. 2 LINE | DOWN RECEPTION LINE FACING DOWN SIDINGS 31 | UP BRANCH STARTING | GROUND SIGNAL AT N708 POINTS NIL OR 30 OR 18 | SLOT CONTROL GROUND SIGNAL AT N709A POINTS 19 | GROUND SIGNAL RECEPTION NO. 1 LINE HOME | GROUND SIGNAL RECEPTION NO. 2 LINE HOME 31 | GROUND SIGNAL AT 32B + C NIL OR 32 |