

WORCESTER SHRUB HILL STATION - 15th July 1988. - Lever Plate Descriptions.

R.C.

①

	2	3		5	6	7	8	9	10	11	12	13
(space)	UP MAIN HOME	UP MAIN CALLING ON	(space)	UP BRANCH HOME TO UP MAIN 20	UP BRANCH CALLING ON TO UP MAIN 20	UP MAIN INNER HOME	UP BRANCH HOME TO DOWN MAIN 27 28	UP BRANCH CALLING ON TO DOWN MAIN 30 27 28 [28 WHEN C.M. CLEAR]	UP DOWN MAIN STARTING TO UP MAIN 53 41	UP BAY STARTING 48 47	UP MAIN STARTING	UP MAIN ADVANCED STARTING *
14	15		19	20		24	25	26	27	28	29	
UP MAIN ACCEPTANCE	UP BRANCH ACCEPTANCE	(spaces)	UP MAIN DETONATORS OFF ON	DOWN UP MAIN FACING BRANCH 27	(spaces)	LOCO SHED STARTING 30 29	DOWN MAIN FACING LOCO SHED	DOWN MAIN ADVANCED STARTING TO LOCO SHED 29	DOWN MAIN FACING BRANCH	DISC AT 31 ^B 41 30	DISC FOR 31 ^B 31 30	Notes:- * Short lever. † Red(top)/brown. ‡ Blue(top)/black.
* †	* †			* ‡			* ‡		* ‡			

WORCESTER SHRUB HILL STATION - Level Plate Descriptions - 15th July 1988

RJc.

(2)

30	31	32	33		35	36	37	38	39	40	41	42
F.P.L. FOR 31 ^B	UP DOWN MAIN FACING MIDDLE SIDING	DISC UP MIDDLE SIDING	DISC FOR 31 ^A 31	(space)	DISC FOR 37 ^B 53 41 37 OR 42 41 37	DISC FOR 38 ^B 53 41 38 OR 42 41 38	Nº.1 STATION SIDING Nº.2 STATION SIDING 38	DOWN MAIN FACING Nº.1 STATION SIDING	F.P.L. FOR 38 ^A	DISC UP DOWN MAIN STARTING TO DOWN SIDING 42 41	F.P.L.'s FOR 42 ^A 53 ^A	UP DOWN MAIN FACING DOWN SIDING
43	44	45		47	48		50	51	52	53	54	
DISC FOR 42 ^B 39 42	DISC FOR 45 ^B 47 45 OR 48 47 45 11	CARRIAGE BAY BAY SIDING	(space)	F.P.L. FOR 48 ^B	UP MAIN CARRIAGE BAY	(space)	DISC FOR 51 ^A 51	UP MAIN MIDDLE SIDING	DISC AT 51 ^B NIL [33 WHEN 31R 51R]	UP DOWN MAIN FACING UP MAIN	DISC AT 53 ^B 39 53 OR 52	(space)

WORCESTER SHROB HILL STATION - Lever Plate Descriptions - 15th July 1988.

Rtc.

(3)

56	57	58	59		61	62	63	64	65	66	67	68
DISC BACKING FROM DOWN THROUGH SIDING (SLOT) 63 (GF2) <u>OR</u> 65	DISC UP THROUGH SIDING HOME TO UP SIDING OR DOWN MAIN (SLOT) 63 <u>OR</u> 58 66 (GF2) 65 58 *	DOWN THROUGH SIDING <u>UP</u> THROUGH SIDING * ‡	UP THROUGH SIDING HOME <u>65</u> 58 ‡	(space)	DISC SELECTED FROM NORTH SIDING OR FROM HEREFORD SIDING (SLOT) 62 65 (G.F.2) <u>OR</u> 62 65	NORTH SIDING G.F. INTLCKING LEVER FOR NORTH OR HEREFORD SIDINGS * ‡	NORTH SIDING G.F. INTLCKING LEVER FOR UP SIDING * ‡	DISC AT G.F.3 POINTS (SLOT)	UP MAIN THROUGH SIDINGS * ‡	MAINS FACING <u>TO</u> OVER * ‡	DISC BACKING UP MAIN <u>NIL</u> <u>OR</u> 39 53 <u>OR</u> 65 64	DISC DOWN MAIN HOME TO UP MAIN OR THROUGH SIDING <u>39</u> <u>OR</u> 53 66 66 65 <u>OR</u> 64 66 ‡
69		71		75		77	78	79	80	81	82	
(space)	(space)	DOWN MAIN RETONATORS <u>OFF</u> ON	(3 spaces)	DOWN MAIN ADVANCED STARTING TO BRANCH <u>27</u>	76 UP MAIN TO BRANCH STARTING	UP MAIN TO (DOWN) UP MAIN STARTING	DOWN MAIN ADVANCED STARTING	DOWN MAIN CALLING <u>ON</u> 30	DOWN MAIN STARTING <u>30</u>	DOWN MAIN CALLING <u>ON</u> 39	DOWN MAIN INNER HOME <u>39</u>	Notes:- * Short lever ‡ Blue(top)/black ‡ Description reads vertically on lever.
										83 DOWN MAIN HOME <u>39</u>	84 DOWN MAIN DISTANT FOR 83 <u>83</u>	
*												